



Quick-fit Wall Instructions



TO FIT 3 WALLS TO A 3x3, 4x4 OR 2x2M TENT

- 1) Hang wall 1, wrap around front leg. Tip: line up both sets of velcro carefully, starting with the top section & working down to the bottom 2 sections. Pull on the bottom of each flap to get the tensions correct
- 2) Hang wall 2, wrap around r/h rear leg (as seen from front)
- 3) Hang wall 3, wrap around l/h rear leg
- 4) Wrap wall 3 around front leg
- 5) Carefully flap on to rear wall at point 5
- 6) Carefully flap on to rear wall at point 6


Note: to fit closing wall, attach wall, unwrap point 4, wrap closing wall at point 4, flap closing wall at point 1, then flap wall 3 at point 4



TO FIT 2x3M QUICK-FIT WALLS TO A 4.5x3M TENT WITH OLD STYLE 4.5M WALLS

- 1) Hang 4.5m wall 1, and attach all the leg loops on r/h rear leg (as seen from front)
- 2) Hang wall 2, wrap around r/h front leg
- 3) Hang wall 3, wrap around l/h rear leg
- 4) Wrap wall 3 around front leg
- 5) Carefully flap on to rear wall at point 5
- 6) Carefully flap on to rear wall at point 6

Note: to fit 4.5m closing wall, attach wall, unwrap point 4, attach closing wall leg loops at point 4, flap closing wall at point 2, then flap wall 3 at point 4



TO FIT QUICK-FIT WALLS TO A 6x3M TENT
Follow instructions for 3x3, but note how centre leg works